



1 GAME CONSOLES




2 TV, DVD, RECEIVER



3 HANDHELD / IPOD® / MP3



4 MULTI-PLAYER




SAFETY WARNING

- ⚠ WARNING:** This product is intended for indoor use only. TO REDUCE THE RISK OF FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.
- Do not expose to direct sunlight or extreme temperatures.
 - Adult supervision is required for set-up.
 - Use only with the supplied power adapter. The power adapter is not a toy.
 - Power units are intended to be correctly oriented in a vertical or floor mounted position.

Compatible with ALL GAMING CONSOLES, PS2®, PS3®, XBOX®, XBOX 360®, Wii®, Game Cube®, Nintendo DS®, DS Lite®, PSP®, IPOD®, TV, VCR, DVD and MP3 players.

- Excessive use of audio equipment at high volume may lead to hearing loss. Listen responsibly and use common sense.
- Children under 13 should not use this product without parental supervision.
- DO NOT wash or soak the unit with water. If cover becomes wet, disconnect power immediately and do not use until totally dry.
- To avoid injury or death from electrical shock, NEVER open the electrical cabinet or remove the cover.
- Keep hands clear from folding seam when opening the Game Chair.

5 HDMI



TROUBLESHOOTING

I can't hear sound from my unit?

If you cannot hear sound from your unit please re-check your cable connection and make sure all cables are securely connected.

A common set-up mistake is plugging the audio cables into the Red and White AUDIO INPUT of your Television or AV source. Sound will not play from the unit when plugged into an AUDIO INPUT source. To correctly connect the cables you must connect to an AUDIO OUTPUT source.

The power on my unit does not turn on?

Check to make sure the outlet you are using is in working condition, and the power adapter is securely connected to the unit. Press the power button on the control panel and the LED light will light up. If you have tried this procedure and your unit still does not turn on you may need a new power adapter.

FCC AND IC STATEMENT

FCC part 15.21:

⚠ Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC part 15.105:

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

